






Panel Mounting Kits Assembly





① Put the Mounting Kits into the Mounting Holes






Mounting Kits

② Fix Panel PC with their fixture by M4 Screws





Wall  
Mounting Kits Section



4				
3				
2				
1				
Mark	Description	Date	Sign	

Portwell Inc.

7F, No. 242, Bo-Ai St., Shu-Lin City, Taipei County 238, Taiwan  
Tel: +886-2-7731-8888 Fax: +886-2-7731-9888

TOL #										TITLE	CUTOUT-SIZE	DWG. NO.	B712	DATE	03/31/16
RANGE	M1	M2	S1	S2	P1	P2	C	P/C	MODEL	Javi-1230	PARTS NO.	B712	Viewpoint		
0~6	.05	.01	.15	.02	.05	.01	0.5	0.2	MATERIAL		APPROVED:		SCALE	1=1	
7~30	.01	.02	.15	.25	.01	.15	1	0.2							
31~80	.15	.25	0.2	0.3	0.2	0.4	2	0.2							
81~180	.15	.03	.25	.45	0.4	0.8	3	0.25							
181~315	.02	0.5	0.4	0.6	0.6	1.2	3	0.3	FINISH		DRAWN	Daniel	UNIT	mm.	
316~800	0.3	0.8	0.7	1.1	0.8	1.5	4	0.4							